

Parameter	EbikeBC default Value	Description
P1	87	Motor Characteristic Parameter Setting Mode
P2	1	P2 Wheel Speed Pulse Signal Setting Mode
P3	1	PAS torque emulation
P4	0	Handlebar Startup Mode
P5	12	Power Monitoring Mode
C1	7	Power Assist Sensor and Parameter Select Mode
C2	0	Motor Phase Classification Coding Mode
C3	2	Power Assist Ratio Gear Initialization Mode
C4	0	Handlebar Function Setting Mode
C5	8	Controller Maximum Current Adjustment Mode
C6	2	Backlight Brightness Adjustment Mode
C7	0	Cruise Function Setting Mode
C8	1	Motor Operating Temperature Display Mode
C9	0	Startup Password Setting Mode
C10	n	Automatically Restore Default Setting Mode
C11	0	Attribute Selection Mode
C12	4	Controller Minimum Voltage Adjustment Mode
C13	4	ABS brakes of the controller and parameters of anti-charge control
C14	3	Power-assist tuning parameters