



# ***BionX***<sup>®</sup>

## ***DV Battery Template***



Cut out the battery template, use the markings over the bottle cage holes on the bicycle frame. The flat holes must be used together, the countersunk holes with the corresponding countersunk hole. Always attempt to use flat holes first. Leave 2.5cm (1") on the rear side (by the handle) for clearance when removing the battery.

**MUST BE PRINTED FULL SIZE**



***DV Battery Template***

FLAT

CS

CS

FLAT

CS

64 MM


**Flat = Flat holes and button head screws**

**CS = Countersunk screws and holes**

**NO = Do not use for alignment (OEM only)**

# ***BionX***<sup>®</sup>


***DV, DX (Global)  
and DL (EU ONLY)  
Battery Template***



**Cut out the battery template, use the markings over the bottle cage holes on the bicycle frame. The flat holes must be used together, the countersunk holes with the corresponding countersunk hole. Always attempt to use flat holes first. Leave 2.5cm (1") on the rear side (by the handle) for clearance when removing the battery.**

# MUST BE PRINTED FULL SIZE


**Note: Please see alternate DL battery for  
NA Only**



**Flat = Flat holes and button head screws  
CS = Countersunk screws and holes  
NO = Do not use for alignment (OEM only)**

# BionX<sup>®</sup>


## DL (NA ONLY) Battery Template



Cut out the battery template, use the markings over the bottle cage holes on the bicycle frame. The flat holes must be used together, the countersunk holes with the corresponding countersunk hole. Always attempt to use flat holes first. Leave 2.5cm (1") on the rear side (by the handle) for clearance when removing the battery.

# MUST BE PRINTED FULL SIZE

**Note: This battery and harness are not compatible with any other battery or dock**



Flat = Flat holes and button head screws  
CS = Countersunk screws and holes  
NO = Do not use for alignment (OEM only)